

# LELO

## MAHANA™ Originals



USER MANUAL

MAHANA\_Originals\_PUB1\_Q325

Part of the exclusive LELO Originals series, MAHANA™ Originals makes every connection between lovers more unforgettable.

**Enjoy it often, wisely and with care.**

Congratulations on acquiring MAHANA™ Originals. Before getting more closely acquainted with it, please take a moment to look through this user manual.

## **IMPORTANT**

Your pleasure object has been locked for transportation. To unlock, simply connect the charger or see below.

## **SAFETY**

- Please consult your healthcare provider with any questions or concerns you may have regarding your condition.
- This product can be used by adults only. Keep out of reach of children.
- People with reduced physical, sensory or mental capabilities or lack of experience and knowledge should use the device only if they have been given supervision or instruction concerning the use of the device in a safe way and understand the hazards involved.
- Only use the product for the intended purpose. Sharing sex toys with other people may transmit sexual diseases. Do not share your sex toys with people other than your partner.
- Use protective measures with your partner if necessary.
- Do not use the product if you detect any cracks or signs of degradation on the covering material.
- To prevent stains, do not keep your product on the absorbent surfaces. If your product operates abnormally, turn off and consult the support section on our website.
- Do not use the product if one or more components are damaged.

## **COMPLIANCE STATEMENT**

### **a. WARNING**

Please take note that changes or modifications not expressly approved in writing by the party responsible for compliance could void the user's authority to operate the device and/or void any relevant warranties.

### **b. FCC and IC statements**

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This class B digital apparatus complies with Canadian ICES-003.

### **b. Déclarations de la FCC et de l'IC**

Cet appareil répond aux exigences de l'article 15 du Règlement de la FCC et aux normes RSS exemptes de licenciement d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes :


- (1) cet appareil ne doit pas causer d'interférences nuisibles, et
  - (2) doit accepter toute interférence reçue, notamment celles susceptibles d'entraîner un fonctionnement indésirable.
- Cet appareil numérique de classe B est conforme à la norme canadienne NMB-003.

## NOTE

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorienting or relocating the receiving antenna.
  - Increasing the separation between the device and receiver.
  - Connecting the device into an outlet on a circuit different from that to which the receiver is connected.
  - Consulting the seller, the device dealer or an experienced radio/TV technician for help.
  - The device has been evaluated to comply with general RF exposure requirements.
  - The device can be used in portable exposure conditions without restriction.
  - This device complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.
  - Users can obtain Canadian information on RF exposure and compliance.
- 
- Cet appareil ne doit pas être placé près d'une autre antenne ou d'un autre émetteur ou fonctionner conjointement avec ceux-ci.
  - L'appareil a été évalué pour répondre aux exigences générales d'exposition aux fréquences radio.
  - Il peut être utilisé dans des conditions d'exposition portable sans restriction.
  - Cet équipement est conforme aux limites d'exposition stipulées par IC RSS-102 pour un environnement non contrôlé.
  - Les utilisateurs peuvent obtenir des renseignements canadiens sur l'exposition aux fréquences radio et sur la conformité.

## GETTING TO KNOW YOUR MAHANA™ Originals



### HOW TO FIND FCC ID AND IC INFORMATION IN THE USER APP:

- Open the "LELO™ app"
- Click "Menu"
- Click "Legal & Regulatory"
- Click "MAHANA™ Originals"
- FCC ID: ZT5-ORIGINAL 2
- IC: 9798A-ORIGINAL 2
- HVIN: MAHANA™ Originals
- PMN: Handheld massager

## USING YOUR MAHANA™ Originals

LELO Originals have app lock to ensure your device is genuine, up-to-date, and safe to use. Once you unlock the device, you can choose whether to use the app or not.

### With the LELO™ app

- Charge your MAHANA™ Originals for 2 hours before first use
- Download the LELO™ app for [iOS](#) or [Android](#), or scan the QR code on the box
- Press the power button on the device — the LED will blink (pairing mode)
- Once you register and sign in the LELO™ app, choose the Originals series and connect your device
- Press the power button again to confirm pairing
- Your device is now unlocked and ready to use with the app

#### Features in the app:

- 8 modes total (4 standard + 4 extra inside the app). Go to **Settings** to adjust modes and other preferences
- Tap **Save** to store your settings for offline use
- Set auto power-off to 10–20 minutes in the drop-down menu
- Battery level shows in the upper-left corner of the app

For more information about the LELO™ app, use the detailed instruction manual located [HERE](#).

### Without the LELO™ app

- Charge for 2 hours before first use
- You still need to unlock the device via the LELO™ app when you use it for the first time (see steps above)

#### Once unlocked:


- Press (O) to turn it on
- Press (O) to cycle through 4 modes
- Press and hold (O) to turn off the device

## USING MAHANA™ Originals

### How to hold



### Where to place



Keep in mind that after 20 minutes of inactivity, MAHANA™ Originals will initiate automatic shutdown to save battery.

**Tip:** For an even more pleasurable sensation, apply a liberal amount of LELO Personal Moisturizer to your body and to MAHANA™ Originals before and during use.

## **CHARGING YOUR MAHANA™ Originals**

- Insert the DC plug into the DC port at the base of your MAHANA™ Originals.
- Insert the mains plug into a USB Port. The LED on the interface of your MAHANA™ Originals will pulse to indicate it is charging. When it is fully charged, the LED will emit a steady glow. When the battery is running low, the LED on your MAHANA™ Originals will emit a blinking white light.



**Only use original chargers provided by LELO with your MAHANA™ Originals.**

## CLEANING, STORAGE, AND SAFETY

Using MAHANA™ Originals with hand creams or silicone-based lubricants may make the silicone permanently tacky.

MAHANA™ Originals is fully waterproof, making cleaning simple. Rinse and spray with LELO Toy Cleaner, then rinse again and allow it to dry.

Always clean your MAHANA™ Originals thoroughly before and after each use. You can wash the silicone with warm water and antibacterial soap, rinse with clean hot water, and pat dry with a lint-free cloth or towel. Never use cleansers containing alcohol, petrol, or acetone.

Avoid leaving your MAHANA™ Originals in direct sunlight and NEVER expose it to extreme heat.

Store your MAHANA™ Originals in a dust-free place and keep it away from products of other materials.

The appliances must only be supplied at SELV.

## TROUBLESHOOTING

**The LED on your MAHANA™ Originals does not pulse when the charger is connected?**

- The battery is drained and will require several minutes to acknowledge that it is being charged.
- The charger is not properly connected. Check wall and DC sockets.

**Your MAHANA™ Originals does not activate when the (()) button is pressed:**

- The battery is empty. Recharge your MAHANA™ Originals.

If you experience any other problems with your MAHANA™ Originals or if you have any questions regarding the operation, please contact:  
**[customercare@lelo.com](mailto:customercare@lelo.com)**

## SPECIFICATIONS

**Materials:** Body-safe silicone, ABS and nylon plastic

**Finish:** Smooth

**Size:** 84.5 x 30 x 43 mm / 3.3 x 1.2 x 1.7 in

**Insertable length:** 78 mm / 3.1 in

**Weight:** 42 g / 1.5 oz

**Battery:** Li-Ion 70 mAh

**Charging:** up to 2 h at 5 V 70 mA

**Rated Power:**

- Input: 5 V 70 mA 0.35 W
- Output: 3.7 V 180 mA 0.67 W

**User time:** up to 2 h

**Standby:** 90 days

**Frequency:** 105 Hz

**Max. noise level:**  $\leq 63$  dB

**Interface:** 1 button

## **REGISTER WARRANTY**

To activate your 2-year Limited Warranty, register the number provided on the LELO Authenticity Card at [LELO.COM/SUPPORT](https://LELO.COM/SUPPORT).

## **2-YEAR WARRANTY**

LELO warrants this pleasure object for a period of TWO (2) YEARS, after the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover cosmetic deterioration caused by fair wear and tear or damage caused by accident, misuse, or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify LELO during the warranty period, LELO will, at its discretion, replace the pleasure object free of charge. Claims under warranty must be supported by reasonable evidence that the date of claim is within the warranty period. To validate your warranty, please keep your original purchase receipt together with these warranty conditions for the duration of the warranty period. To claim your warranty, you must log in to your account at [LELO.COM](https://LELO.COM) and then select the option to make a warranty claim. Shipping costs are non-refundable. This undertaking is in addition to the consumer's statutory rights and does not affect those rights in any way.

## DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that this pleasure object should not be treated as household waste, but rather be brought to the appropriate collection point for the recycling of electrical and electronic equipment.



RoHS



UK  
CA

FC



SERIAL NO.

SN

IPX 7



MANUFACTURE DATE



CLASS B DIGITAL APPARATUS



FOLLOW INSTRUCTIONS FOR USE



ETICHETTA AMBIENTALE	
1	SCARTOLA COLORATA RACCOLTA IN CARTONINO
2	SCARTOLA IN CARTONINO RACCOLTA PLASTICA
3	VALIGIO IN EVA RACCOLTA PLASTICA
4	SEZIONI NON ELEGIBILI RACCOLTA PLASTICA
5	PIRESE CON RETE RACCOLTA PLASTICA
6	MANGIALE RACCOLTA CARTA

Hereby, LELOi AB declares that the radio equipment type [Non-Specific Short Range Device] is in compliance with Directive 2014/53/EU. LELOi AB declares that the product is also compliant with Directive 2011/65/EU (RoHS). The full text of the EU declaration of conformity is available at the following internet address: <http://www.lelo.com/regulatory>

**DISCLAIMER:** Users of this product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Changes or modifications not expressly approved by the manufacturer may void the user's authority to operate the equipment. The model may be changed for improvements without notice.

© 2025 LELOi AB. All rights reserved.

LELOi AB, Karlavägen 41, 114 31 Stockholm, Sweden.

Distributed in the US by LELO Inc., 5799 Fontanoso Way, San Jose, CA 95138, USA.

Distributed in Australia by LELO Oceania 6 Prohasky Street, Port Melbourne, VIC 3207, Australia.

Designed and developed by LELO Sweden.

Made in China.

US and International patents or patent applications apply to this product: visit <https://www.lelo.com/intellectual-property>

[www.lelo.com](http://www.lelo.com)